Job Feedback/Historical Notes:

DO SO.

4. REINSTALL THE INSULATING MATERIALS

REMOVED AFTER THE MODIFICATIONS HAVE BEEN COMPLETED, AND YOU HAVE BEEN DIRECTED TO

5. CLEAN UP AFTER YOURSELF.



Delays

** IMPORTANT NOTICE ** YOU ARE RESPONSIBLE FOR YOUR OWN SAFETY AND MUST

ENSURE THAT THE REQUIRED PPE IS WORN FOR EVERY

JOB YOU ARE DOING. IF YOU HAVE ANY QUESTIONS

CONCERNING THE WORK RULES, SAFETY CODES, OR

REQUIRED PPE, PLEASE CONTACT YOUR SUPERVISOR.

* CREW 57 (JIM KELSEY, x6853) HAS THE

* LOCATION: UNIT-1 BOILER AREA, 9TH

FLOOR, OFA DUCTS.

LEAD WORK ORDER. I&C (JOHN FRITZGES, x6411) HAVE A SUPPORT WORK ORDER.

* KEN NIELSON (x6437) AND PHIL HAILES (x6438) ARE THE ENGINEERS RESPONSIBLE FOR

02-60456-46 ISSUE DATE 01/06/11 Page 3 Of 3

CREW: 97 WORK ORDER TYPE: MODIFICATIONS

| ** Work Order Tools List ** | | | | | | |
|-----------------------------|---------|------------------------------|-------------|-----------|-----------|-----|
| Ln | Tool No | Noun Qualifier | Measure 1 | Measure 2 | Measure 3 | Rqd |
| | | | | | | |
| 1 | 5330 | SCAFFOLDING, | 5'6" | 4 RUNG | | 4 |
| 2 | 5322 | SCAFFOLDING, | 6' PLATFORM | | | 8 |
| 3 | 5323 | SCAFFOLDING, PLATFORM | 6' | | | 2 |
| 4 | 5320 | SCAFFOLDING, COUPLER HEX NUT | RT. ANGLE | ALUMINUM | | 6 |